

# Designing Earthquake Protection for Fire Sprinkler Systems

## Using the Model Building Codes

J. Scott Mitchell, P.E.


In the September 2003 issue of *Sprinkler Age* we presented the steps to determine whether or not earthquake protection is required for a particular project. We pointed out that protection is no longer based solely upon the zone number from the NFPA 13 seismic map and that a sprinkler system in one building might require earthquake protection while a system in a nearby building may not. Then, in the November 2003 issue, we discussed developments in the relationship between using the *Building Construction and Safety Code (NFPA 5000)*, the *International Building Code (IBC)*, and NFPA 13. We also gave justification for only using NFPA 13 when designing for earthquake protection, although it may not be permitted by the explicit wording of the model building codes. In this third and final article, we will present an example of how to calculate force factors used to design earthquake protection based on building code criteria and identify the major problem with those criteria. As you read this article, keep in mind that NFPA 5000 and the IBC both essentially point to American Society of Civil Engineers (ASCE) 7 for criteria on earthquake protection.

The working example for this article is a five-story, 60 ft high hospital in Jonesboro, AR, 72404. Using the step-by-step process outlined in the first article, we must determine whether or not earthquake protection is required for the fire sprinkler system. The hospital is in seismic use group III (ASCE 7:9.1.3, IBC:1616.2). Using the Seismic Design Parameters (SDP) software, we determine the mapped maximum considered earthquake spectral response acceleration at short periods  $S_s$  to be 1.9756g and at 1-second periods  $S_1$  to be 0.597g. There are at least two opportunities for exemption from earthquake protection in this process. The first is found in exception #5 to IBC:1614.1. According to the given parameters, the building in our scenario is not exempt. If the  $S_1$  was less than or

equal to 0.15g and if the  $S_1$  was less than or equal to 0.04g, the building would be exempt. Next, based on information

obtained from the civil engineer for the project, the site is determined to be in Site Class C. It is important to note that

## PT<sup>TM</sup> pipingtools



### same day shipping

Call by 2 pm est...and we'll ship today!

threading machines • wrenches • roll groovers • holesaws  
pipe cutters • dies • pipestands • hydrostatic test pumps  
thread sealants • cutting oils • pipe fab equipment

1.800.854.1015  
[www.pipingtools.com](http://www.pipingtools.com)

the A/E building design team is expected to have this information on-hand since it is required for other seismic aspects of the building itself. However, if this information cannot be obtained, the default is Site Class D, which is more demanding than most scenarios. Using the SDP software, which includes the site class factors ( $F_a = 1.0$ ,  $F_v = 1.3$ ), the maximum considered earthquake spectral response acceleration for short periods  $S_{MS}$  is 1.9756g and at 1-second periods  $S_{M1}$  is 0.777g. Then the design spectral response accelerations are determined at short periods  $S_{DS}$  to be 1.3171g and at 1-second periods  $S_{D1}$  to be 0.518g (ASCE 7:9.4.1.2.5, IBC:1615.1.3). Here is the second opportunity for exemption. Exception #6 to IBC:1614.1 allows that where  $S_{DS}$  is less than or equal to 0.167g and where  $S_{D1}$  is less than or equal to 0.067g, the building is exempt. The building is still not exempt. Finally, the building is placed in Seismic Design Category F based on both the short and 1-second period response accelerations (ASCE 7:9.4.2, IBC:1616.3). To this point in the process there are no exemptions for this building that would allow omission of earthquake protection, so protection must be provided.

NFPA 5000:35.10 and IBC:1621 both refer to ASCE 7, Section 9 for design and

construction to resist the effects of earthquakes. ASCE 7:9.6.23.11.2 allows the use of NFPA 13 for the design and construction of the earthquake bracing system provided force and displacement requirements of ASCE 7:9.6.1.3 and ASCE 7:9.6.1.4 are satisfied. This means we can use NFPA 13, but with a caveat. We have to verify that the NFPA 13 design will meet or exceed the force and displacement design from ASCE 7.

First we will calculate the design forces for sizing braces to be installed on portions of the fire sprinkler system in our hospital. Despite the entire system being protected, we intentionally said "portions" since the design force differs throughout the building for the same size piping. NFPA 13 uses the same design force throughout regardless of height. For this example, the  $F_p$  calculated from NFPA 13 is 560 lbs. This is based on a calculated weight of water filled pipe in the zone of influence of 973.9 lbs, a force factor  $W_p$  of 0.50, and a miscellaneous fittings and components factor of 1.15. The  $F_p$  calculated from NFPA 13 must be compared to the  $F_p$  calculated from ASCE 7 and the larger value used to size the brace. This value is calculated from ASCE 7 using a base formula and two bounding formulas (ASCE 7:9.6.1.3) as follows.

$$F_p = \frac{0.4a_p S_{DS} W_p}{R_p / I_p} \left( 1 + 2 \left( \frac{z}{h} \right) \right)$$

$F_p$  is not required to be greater than

$$F_p = 1.6 S_{DS} I_p W_p$$

and  $F_p$  shall not be less than

$$F_p = 0.3 S_{DS} I_p W_p$$

where:

$F_p$  = seismic design force

$S_{DS}$  = design short period spectral acceleration (1.3171g calculated above)

$a_p$  = component amplification factor (1.0 for sprinkler systems)

$I_p$  = component importance factor (1.5 for sprinkler systems)

$W_p$  = component operating weight (973.9 lb in our example)

$R_p$  = component response modification factor (3.5 for sprinkler systems)

$z$  = height of attachment point with respect to the base (55 ft in our example)

$h$  = average roof height with respect to the base (60 ft in our example)

The above formulas set limits on the force used to size the earthquake protection components. For example, if you calculate  $F_p$  to be 3000 lbs but the first upper bounding formula results in  $F_p = 2745$  lbs, then you are only required to design the component to withstand a force of 2745 lbs. You are free to design it using an  $F_p$  of 3000 lbs, but it is not required. Conversely, you may calculate an  $F_p$  to be 200 lbs, but the lower bounding formula results in  $F_p = 273$  lbs. You must design the component to withstand a force of at least 273 lbs, but not less.

Back to the base formula and substituting all the values:

$$F_p = \frac{0.4(1.0)(1.3171)(973.9)}{3.5/1.5} \left( 1 + 2 \left( \frac{55}{60} \right) \right)$$

and solving we have:

$$F_p = 623 \text{ lbs}$$

Also be aware of the minimum and allowed maximum loads discussed earlier.

Substituting and solving we have:

$$F_p = 1.6(1.3171)(1.5)(973.9) = 3078.5 \text{ lbs}$$

$$\text{and } F_p = 0.3(1.3171)(1.5)(973.9) = 577.2 \text{ lbs}$$

This means that the design load for any brace in our example is not required to exceed 3078.5 lbs and is not permitted to be less than 577.2 lbs regardless of location. Also, notice that the value calculated using ASCE 7 is greater than the value calculated using NFPA 13. The higher value must be used to size the brace components.

Now, let's take the same scenario and move it to the first floor of the hospital at approximately 8 ft above finished floor. This will show the impact of where the

## LONG-TERM CONNECTION PROTECTION



Knox Locking  
FDC Plug

Help the fire department control FDC access by installing a locking Knox FDC Cap™ that protects the connection from tampering and potential fire sprinkler system damage.

The Knox locking plug is solid stainless steel for long-term protection. Both the plug and a locking Storz cap are quickly and easily removed with a Knox Keywrench™.

Call 800-552-5669



17672 Armstrong Avenue, Irvine, CA 92614 • www.knoxbox.com  
Fax (949) 252-0482 • E-mail: info@knoxbox.com



brace is located within the building. The only variable changing in the equation would be  $z$ , which would now be 8.

Substituting and solving we have:

$$F_p = 278.5 \text{ lbs}$$

Note that the design load from the fifth floor is 623 lbs, but on the first floor it is 278.5 lbs for the same size zone of influence. This difference reflects the expectation that more loading will be induced on components located higher in the building than components located lower in the building, due to the building's movement in an earthquake.

The calculated design force for our first floor brace was less than the minimum allowed, so it must be designed to the minimum 577.2 lbs. Also note that the NFPA 13 calculated design load was 560 lbs, which is also less than the minimum. Once the design load  $F_p$  is established, using either building code or NFPA 13 criteria, select and size the brace components using NFPA 13.

Now, let's look at displacement and deflection. This is where the problem starts. If you are accustomed to using NFPA 13 in designing earthquake protection, you probably aren't familiar with these terms. These aspects are not brought out in the text and formulas of NFPA 13. This may be because they are already addressed in the NFPA 13 design criteria

by the very nature of the materials used in fire sprinkler systems and the maximum allowed spacing of certain components.

Since these terms are not adequately defined, here is an analogy to help us understand their meaning. Let's say you get out your favorite fishing rod, set the reel end on the ground, and stand the rod upright. Secure it about half way up with your left hand. Now with your right hand move the tip of the rod in any direction bending the rod. Notice how the rod bends? This is deflection. Now, take note of the rod tip's new location relative to its original location. This is displacement. Notice that some parts of the rod are displaced farther from their original locations than others. In an earthquake, a building will deflect similarly. When it deflects, portions of the building are displaced from their original location. Some parts are displaced farther than others.

Again, ASCE 7:9.6.3.11.2 allows NFPA 13 designed earthquake protection provided the force and displacement requirements of ASCE 7:9.6.1.3 and ASCE 7:9.6.1.4 are satisfied. But, how do you verify that displacement from NFPA 13 satisfies ASCE 7, when NFPA 13 does not directly address displacement? This can cause a major problem, especially if an AHJ is very literal in interpreting codes and standards. ASCE

7 prescribes a method for determining displacement and, in doing so, presents another problem. Although it may not be absolutely necessary to understand this method, as much as possible is presented here for your benefit. The seismic relative displacement required by ASCE 7:9.6.3.11.2 and 7:9.6.1.4, can be calculated using the formula:

$$D_p = \delta_{xA} - \delta_{yA}$$

where:

$\delta_{xA}$  = the deflection in the building at Level  $x$ , as determined by an elastic analysis as defined in ASCE 7:9.5.5.7.1

$\delta_{yA}$  = the deflection in the building at Level  $y$ , as determined by an elastic analysis as defined in ASCE 7:9.5.5.7.1.

Then ASCE 7:9.5.5.7.1 discusses story drift (displacement) as being the difference of the deflections at the top and bottom of the story under consideration and gives the following formula for calculating deflections at each story level.

$$\delta_x = \frac{C_d \delta_{xe}}{I}$$

where:

$C_d$  = the deflection amplification factor in ASCE 7:Table 9.5.2.2


$\delta_{xe}$  = the deflections determined by an elastic analysis

## YOUR BEST VALUE IN RESIDENTIAL WATER DELIVERY SYSTEMS

# Take A Closer Look!


### THE D-SYSTEM:

A complete pre-wired factory assembled unit. Installs in 3 easy steps.

Meets NFPA quality standards. Components UL approved. 

### THE D-CONO LINE:

New super affordable systems. Tanks available to fit 29" doorway.




Home Fire Sales, Inc., Patent #4366865

**800-PUMP 13D**  
(800-786-7133)

[www.thedssystem.com](http://www.thedssystem.com)

## There's no question about the benefits of AFSA products.



AFSA's training and education products cover the gamut of fire sprinkler industry needs such as:

- Apprenticeship
- System Design
- Foremanship
- Inspection
- Management
- NFPA and other codes
- Safety
- Public Education

AFSA's product range includes:

- Correspondence courses
- Inspection Forms
- Designer and Fitter Resources
- Publications
- Training Kits
- Videos
- Programs
- Seminars

Visit [www.sprinklernet.org](http://www.sprinklernet.org) to find answers to your questions.

I = the importance factor determined in accordance with ASCE 7:9.1.4

The seismic protection for both the building and its systems must accommodate the displacements and deflections discussed here. It appears that these displacements and deflections are only of significance in systems and buildings that have a significant change in elevation. That is, a system entirely located at a single elevation in a building such as the piping down-stream from a floor control valve will not experience these types of displacements and deflections. It appears that these are only experienced by pipes with multiple elevation attachment points in the building, such as a standpipe/sprinkler system riser in a high-rise building.

We must point out that the deflections ( $\delta_{se}$ ) can only be determined by an elastic analysis. At this point you should kneel down and pray that your contract has not put this totally in your lap or bow your head in tears, if you already know it has. Because, unless you have one in-house, you'll have to go out and hire a consulting structural engineer to perform an elastic analysis. Really, someone on the A/E building design team should have already performed an elastic analysis and calculated the building deflections and displacements for each level. These numbers can then be compared to the amount of deflection accommodated by vertical fire sprinkler or standpipe riser piping using listed flexible couplings.

Looking at this article's example and NFPA 13:9.3.2, we see that at least 10 listed flexible couplings will be installed (two on each floor) in each vertical riser. By definition (NFPA 13:3.5.4), listed flexible couplings are required to allow axial displacement, rotation, and at least 1 degree of angular movement of the pipe without inducing harm on the pipe. Considering 10 flexible couplings each allowing one degree of movement, installed at the NFPA 13 required locations, the cumulative minimum available displacement at the top of the riser would be approximately 5½ ft. That's quite a bit of movement for the fifth story of a building. It can be expected that if the fifth story of a building moves this much, the sprinkler system piping probably won't be needed any more.

With regard to deflection and displacement, we conclude that vertical piping in all buildings of significant height will inherently be protected by listed flexible couplings, when installed in accordance with NFPA 13. This more than adequately satisfies the requirement of ASCE 7:9.6.1.4 (thus the building codes) regarding displacement.


This article has covered, as much as

possible, how to design a seismic protection system in accordance with the model building codes referencing ASCE 7. A tentative interim amendment (TIA 02-1) was issued that changed the NFPA 13 criteria for earthquake protection. This measure brings the NFPA 13 criteria into alignment with ASCE 7. Additionally, changes are expected in ASCE 7 in the forthcoming 2005 edition. Word has it that the paragraph (9.6.3.11.2) in ASCE 7 referencing NFPA 13 will be changed. Instead of saying that you can use NFPA 13, provided force and displacement requirements are satisfied, it will simply say that NFPA 13 can be used. This will

allow designers to use NFPA 13 alone to design the earthquake protection for fire sprinkler systems. Let's all cross our fingers and hope this comes to fruition. ☛

#### ABOUT THE AUTHOR:

J. Scott Mitchell, P.E. is a fire protection engineer for AFSA's Technical Services Department. He holds a Bachelor of Science in Engineering Technology from Oklahoma State University. Mitchell sits on four NFPA technical committees, including NFPA 13 hanging and bracing technical committee. He is a member of SFPE.



# FPC

Fire Protection Contractor magazine

## YOU NEED TO KNOW

How do you find fire sprinkler industry manufacturers, suppliers, fabricators, independent designers, consultants and others serving the fire sprinkler industry?

## WE MAKE IT EASY

Finding what you are looking for will be a breeze in *FPC's* new *2005 Sprinkler Industry Directory* — the most complete listing of fire sprinkler industry products and services available.

*FPC's 2002 Sprinkler Industry Directory* was a huge success. Many in the industry are still using this directory on a daily basis. You'll want this new directory at your fingertips.

The *2005 Directory* will have over 50 categories and sub-categories of products and services, cross-referenced and indexed in 196 pages, with over 1,000 companies and individuals listed, in more than 1,300 listings.

The *2005 Sprinkler Industry Directory* will be available in December, 2004 — all subscribers to *FPC magazine* will receive a copy.

For more information, visit our Website: [www.fpcmag.com](http://www.fpcmag.com), or contact:

#### *FPC/Fire Protection Contractor*

12972 Earhart Avenue, Suite 302, Auburn CA 95602  
(530) 823-0706 Fax 530-823-6937 E-mail: [info@fpcmag.com](mailto:info@fpcmag.com)

It may not be too late to advertise or get listed in the Directory! For deadlines and listing information, please call (530) 823-0706 or reference our website at [www.fpcmag.com](http://www.fpcmag.com)